



2022-2023

PADDLE IN STYLE | [WWW.AQUATONE.COM](http://WWW.AQUATONE.COM)

AZTRON SPORTS (SHANGHAI) CO.,LTD



**aquatone**

PADDLE IN STYLE | [AQUATONE.COM](http://AQUATONE.COM)

EN



**AIR PLATFORMS AND CHAIR**  
USER GUIDE

## < WELCOME >

Thank you for choosing an aquatone product. This product is built in accordance with strict quality standards and premium craftsmanship. We hope you thoroughly enjoy this product. Please take the time to read the content in this manual in order to optimize your satisfaction of this product. We believe that an aquatone product offers incomparable value.


We wish you years of enjoyment and rewarding experience with your aquatone product.

## < INDEX >

2. Info and Serial Number
3. Product Overview
8. Safety Precautions
9. Before Inflation- Tighten Air Valve
10. Installation and Inflation
11. Deflation, Maintenance & Storage
12. How to Fold the Platform
12. How to Fold the Air Chair
13. Repair
14. Warranty Info and Warranty
15. Registration Card

## < SERIAL NUMBER >

You can find the Product Serial Number at the back of the product. See below for example.



## < IMPORTANT INFORMATION >

Model:

Date of Purchase:

Dealer Name:

Province/State:

Country:

Item No:

Serial #:


Follow us at Aquatone   

www.aquatone.com

All data subject to change @AQUATONE 2022-2023  
AQUATONE is a registered trademark of Aztron Sports.

## < PRODUCT OVERVIEW >


### CLUB PLATFORM – TP-008



|   |                                     |   |                               |
|---|-------------------------------------|---|-------------------------------|
| A | High pressure air valve             | B | Smart folding line            |
| C | Adjustable nylon straps on the deck | D | Multiple grab handles         |
| E | All-wrapped soft EVA traction pad   | F | D-ring connectors for docking |
| G | Mega gear bag                       | H | Repair Kit                    |

< PRODUCT OVERVIEW >


AIR CHAIR – TP-200



|   |                                         |   |                        |
|---|-----------------------------------------|---|------------------------|
| A | Top carry handle                        | B | Compressed nylon strap |
| C | High pressure air valve                 | D | Cup holder             |
| E | Storage pocket and nylon strap riggings | F | Gear backpack 105L     |
| G | Repair kit                              |   |                        |

< PRODUCT OVERVIEW >


MANTA SWIMMING PLATFORM – TP-150



|   |                         |   |                                    |
|---|-------------------------|---|------------------------------------|
| A | High pressure air valve | B | Safety net                         |
| C | Multiple grab handles   | D | D-ring connectors on deck and back |
| E | Mega gear bag           | F | Repair Kit                         |

< PRODUCT OVERVIEW >


ONEUS WATER & LAND PLATFORM – TP-300



|   |                                    |   |                       |
|---|------------------------------------|---|-----------------------|
| A | High pressure air valve            | B | Multiple grab handles |
| C | D-ring connectors on deck and rail | D | Gymnastic lines       |
| E | Velcro pads on the Land Side       | F | Mega gear bag         |
| G | Repair kit                         |   |                       |

< PRODUCT OVERVIEW >

FLUID FITNESS PLATFORM – TP-100



|   |                                                 |   |                                               |
|---|-------------------------------------------------|---|-----------------------------------------------|
| A | High pressure air valve                         | B | Stainless steel D-ring Connectors on the rail |
| C | Soft EVA traction pad                           | D | Carrying handle on the back                   |
| E | Bungee system and PVC D-ring connectors on deck | F | Multiple grab handles                         |
| G | Gear backpack 105L                              | H | Double action pump                            |
| I | 9' safety coil leash                            | J | Repair kit                                    |

## < SAFETY PRECAUTIONS >

Water sports can be dangerous and physically demanding. There is a risk of serious injury or death from drowning. The user of this product acknowledges, understands, and assumes the risk involved in water sports. Observe the following safety standards and safe operating practices whenever using this product.

When using an aquatone product, you are personally responsible to determine if you have the required skill level to handle the different water and wind conditions. You should use your best judgement as to when and where to use your product. All users of an aquatone product agree to assume all responsibilities for any damage or injury. Including death, which may result from using or handling water sports product.

### WARNING

A **WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.

1. **Check** weather conditions and water levels before heading out.
2. **Always** wear an approved personal flotation device (PFD) before you start paddling, read the manufacturer's documentation about your PFD and familiarize yourself with how to properly wear it. (Always wear safety leash).
3. **Do not** go into water if you are under the influence of alcohol, drugs, or medication as it may affect your condition, judgement or ability to safely and securely operate your product.
4. **Be aware** of your limitation and do not exceed your paddling ability.
5. **Dress** accordingly for weather conditions and.
6. **Always** familiarize yourself with the body of water you intend to navigate and refrain from hazardous environments.
7. **NEVER** let minors use this product without adult supervision.
8. **NEVER** tow this product behind a boat.
9. **NEVER** use this product as a personal flotation device.
10. **NEVER** exceed product's maximum weight.

### CAUTION

A **CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

1. **Check** your equipment prior to each use of signs of wear or failure.
2. **Always** carry identification.
3. **Paddle** alongside someone. It is preferable to be accompanied in case of an emergency or accident.
4. **Always** inform someone about your plan outing, including your destination, duration, amount of people who will be with you.
5. **Follow** Coast Guard regulations, boating, and safety laws, and regulations and orders of various levels of government (including regional laws).
6. **Do not** jump or dive from this item.
7. **Do not** jump onto this item from any other item.
8. **Always** ensure that the swimming area around the air platform is free of submerged logs, rocks and sandbars. Ask about the local water conditions before use.
9. **Do not** use without proper anchoring.
10. **Do not** dive head first or swim under this product.
11. **Never** use at night, or in low-light conditions.

## < BEFORE INFLATION >

### Tighten The Air Valve

Due to the design of the product, the high-pressure valve could become loose during delivery. Therefore, it is important to check that the valve is completely tightened before use. This should also be done periodically to make sure that it remains tight. This will prevent minor losses in pressure and ensure optimum performance of your product.

When inflated and the valve leaks air around the edges, this is because there is not an airtight seal between the PVC fabric of your product and the two sections of the valve. To stop the air leaking, you will need to tighten your valve down solidly by tightening the valve.

**NOTE: The air valve can only be tightened when the product is deflated**



## < HOW TO TIGHTEN YOUR AIR VALVE >



**Step 1:** Remove the valve cap of the inner chamber of the product, and insert the wrench supplied with your repair kit into the valve so it fits tightly.



**Step 2:** Use free hand to apply pressure on to the valve to hold it in place and then firmly twist the wrench clockwise until the valve is completely tightened.



**Step 3:** Put valve cap back on and ensure it is tightened properly

## < HOW TO USE THE AQUATONE PUMP >



**Connect** the hose to the INFLATE section to inflate.



The aquatone Pump is a **Double Action Pump**. Pump the product with the Air Screw closed for double stroke action and take the Air Screw out when the double stroke gets too exhausting.



On top of the pump is a **Pressure Gauge**. The max air pressure is 15psi (beginning of green area on gauge.) **DO NOT inflate the product beyond 15psi, which is the red zone area. This will void the warranty.**

## < PRODUCT INSTALLATION >



**Unpack** the product from the aquatone gear bag on a flat surface to ensure it is free from sharp objects.




**Check that the valve** of the product is in pin-out/upper position. The valve must be released for inflation. To release the valve, unscrew the valve cap, push lightly downwards until the pin's upper/outer position is found.



**Attach the Pressure Gauge** onto the pump. Connect the air hose with a downward push to the pump and plug the end piece of the hose into the valve of the product. Ensure it is secure for a safe connection.

## < SAFETY LEASH SET-UP >



Open the small VELCRO section. Then put the thin rectangular section opened through the D-ring mounted at the end of the board.




**Fold** the lower section of the VELCRO to the top section first.



**Fold** the top VELCRO section down to fasten the safety leash.

**FOR FLUID FITNESS BOARD, USE THE ABOVE INSTRUCTION TO WEAR SAFETY LEASH.**

## < DEFLATION >



**Remove** any water or debris out of the valve area before deflation



**Slowly press down the valve pin** to start letting air out. There will be an initial burst of air, but that will slow down very quickly. Once the air flow has slowed down, press the pin all the way down and turn it clockwise to lock it onto the "OPEN" position.



**To deflate** the product completely, input hose into the deflate option and pump the air out.


## < MAINTENANCE & STORAGE >

- Do not use harsh chemicals to clean the product, rinse the sand and saltwater deposits from the product with fresh water or mild soap.
- Wipe the product dry or let it dry completely before putting the product in the gear bag to prevent dirt buildup.
- Inspect your product for abrasion before and after each use.
- Do not drag the product along the floor as this could result in wearing punctures in the material and will ultimately cause leakage.
- When deflating and packing the product away, place it on a safe surface free from stones and other sharp, hard objects.


### STORAGE

- Store in a cool, clean and dry area after use.
- Do not store your product in extreme temperature conditions (eg above 50°C/122°F or below 0°C/32°F).
- Always store your product deflated as leaving the product inflated can cause strain issues due to changes in temperature and air pressure.

## < HOW TO FOLD THE PLATFORM >



For the wide platform like CLUB or MANTA, fold the product vertically along the center line. Remember to take out all the air before folding the product.




When the product is folded in half, continue to roll the platform from bottom to the top, until it is completely folded.




Use the compression strap in the bag to secure the product. Once it's fastened, put it into the gear bag.

## < HOW TO FOLD THE AIR CHAIR >



Remove all the items from the side pocket first. Start folding from the arms and put them in the center. The seat back should be on the top.




Roll the sofa chair from the side. Use the compression strap on the back to buckle and secure the folded chair.




Store the folded air chair into the 105L backpack.

## < HOW TO REPAIR THE PRODUCT – FIXING A HOLE >




What you need is the Repair Kit (Only PVC pad and valve wrench is supplied), scissors and sandpaper are not supplied.

\*Repair kit does not include the repair glue.



Roughen the area around the hole. Make sure to sand a larger area, around the hole, sand thoroughly in order to roughen the material – this makes the patch stick much better. After that also roughen the patch itself on the side that will be glued on the product.




Put the patch on the hole and press it with your fingers on the product as hard as you can. Rub it with your thumb in order to make it stick to the product properly on all sides. You can also use a piece of hard plastic or something similar to put even more pressure on the glued-on patch.



Cut out a piece of the repair matter included in your Repair Kit to cover the hole. Make sure the patch you cut out is big enough to cover the hole completely. The patch should be about 2cm bigger than the hole on all sides.



Apply the glue on the roughened side of the patch and on the area to be repaired. **ATTENTION:** Do not use too much glue! It should only be a thin layer. Let the glue dry for at least 5 minutes – it should still be soft but not sticky when you put your finger on it.



Leave it to dry for at least 12 hours before next use.

# WARRANTY

**1  
YEAR**

**aquatone warrants this product to be free from major defects in material or workmanship to the original purchaser for a period of ONE (1) YEAR from the date of purchase.**

**This warranty is subject to the following limitations.**

1. The warranty is valid only when the warranty card is completed and returned within 30 days of date of purchase.
2. The warranty is valid only when this product is used for normal recreational activities and does not cover products used in rental or school operations.
3. aquatone will make the final warranty determination, which will require inspection and/or photo of the product, which clearly show the defect(s). Please return the complete aquatone Air Chair & Air Platform package with prepaid postage to the retailer you purchased from and follow their return instructions.
4. If a product is deemed to be defective by aquatone, the warranty covers the repair or replacement of the defective product only. aquatone will not be responsible for any costs, losses, or damage incurred as a result of loss or misuse of the product.
5. This warranty does not cover damage caused by misuse, abuse, neglect; normal wear and tear including, but not limited to, punctures, damage due to excessive heat exposure, damage caused by improper handling and storage, damage caused by use in waves or shore break, product breakage caused by falling or crashing in surf conditions, or damage caused by anything other than defects in material and workmanship.
6. This product must not be modified and/or fitted with a motor.
7. This product must not be used in excess of the manufactures recommended maximum load capacity.
8. This warranty is void if any unauthorized repair, change or modification has been made to any part of the equipment.
9. This warranty for any repaired or replacement equipment is good from the date of the original purchase only.
10. The original purchase receipt must accompany all warranty claims. The name of the retailer and date of purchase must be clear and legible.
11. There are no warranties that extend beyond the warranty specified here in.
12. Register your Air Chair & Air Platform by sending the warranty card located below to your seller or electronically via our website at [www.aquatone.com](http://www.aquatone.com).

## WARRANTY REGISTRATION CARD

Date of Purchase: \_\_\_\_\_ Model: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Dealer/Store Name: \_\_\_\_\_

Dealer/Store Address: \_\_\_\_\_

State/Province: \_\_\_\_\_ Zip/Postal Code: \_\_\_\_\_

Country: \_\_\_\_\_ Mr. ☐ Mrs. ☐ Ms. ☐

Surname: \_\_\_\_\_ Name: \_\_\_\_\_

Address: \_\_\_\_\_

State/Province: \_\_\_\_\_ Zip/Postal Code: \_\_\_\_\_

Country: \_\_\_\_\_

Telephone Number: ( ) \_\_\_\_\_

Email: \_\_\_\_\_